



EAORA10

Datasheet

V1.0.0

ECOTRON CORPORATION

www.ecotron.ai

Revision History

Revision Date	Version	Description
2024.10	V1.0.0	Initial Release

Table of Contents

1. OVERVIEW	4
2. INTERFACE CONFIGURATION	5
3. MECHANICAL STRUCTURE	7
3.1 DIMENSIONAL DRAWING	7
3.2 CONNECTORS	8
4. QUICK START	10
4.1 PREPARATION	10
4.2 BASIC KNOWLEDGE	10
4.3 USING THE DEVICE	10
5. HARDWARE DESCRIPTION	11
5.1 SPECIFICATIONS AND PARAMETERS	11
5.2 DEVICE PORTS	11
5.2.1 <i>Port Distribution</i>	11
5.2.2 <i>Port Definition</i>	14
5.3 SYSTEM MAIN CHIP	18
5.4 CIRCUIT DIAGRAM	20
5.5 CIRCUIT DESCRIPTION	21
5.5.1 <i>Analog Signal Input</i>	21
5.5.2 <i>Digital Signal Input</i>	22
6. BASIC SOFTWARE	23
7. APPLICATION SCENARIOS	25
8. DEVELOPMENT TOOLS	26
8.1 EcoCODER-AI	26
8.2 EcoCODER	27
8.3 EcoCAL	29
8.4 ECOFLASH	30
9. INSTALLATION GUIDELINES	31

1. Overview

The EAORA10 product is an intelligent computing platform developed by **Ecotron Corporation** for autonomous driving systems, aimed at L3-L4 level integrated driving and parking solutions. It integrates an NVIDIA ORIN NX 16G / NVIDIA ORIN NX 8G / NVIDIA ORIN Nano 8G / NVIDIA ORIN Nano 4G chip and an Infineon TC377 chip, combining high-precision maps and positioning navigation. For driving, it can achieve L3-level highway pilot (HWP), traffic jam pilot (TJP), and automatic navigation driving (NOP) functions. For parking, it can reach L4-level memory parking (HPA) and valet parking (AVP) functions.



2. Interface Configuration



Interface Type	Quantity	Function	Internal Chip	Connector
Camera Interface	8	GMSL/GMSL2	SOC	2*4 Cavity Connector
100M Automotive Ethernet	1	100Base-T1	Switch	1*4 Cavity Connector
1G Automotive Ethernet	3	1000Base-T1	Switch	
Standard 1G Automotive Ethernet	3	100BASE-T/1000BASE-T Standard	Switch	3*Aviation Plugs
HDMI	1		SOC	
USB	1	1 USB Host supports USB 2.0, USB 3.0, USB 3.1	SOC	
M.2 KEY M	1	Expandable Storage	SOC	Internal
GNSS	1	Optional	SOC	
WIFI	1	Optional	SOC	
4G	1	Optional	SOC	
5G	1	Optional	SOC	
Audio Interface	1	Optional	SOC	
CANFD	2		SOC	121PIN-CMC
RS232	2	One of the ports is used for Debugging	SOC	
PPS_IN	1	Supports 5V-16V	SOC	
PPM	1		SOC	
Wheel Speed	1		GNSS	
Steering	1		GNSS	
CANFD	8	2 Channels with Specific Frame Wakeup	MCU	
KEYON	3	1 Channel for SoC, 2 Channels for MCU	MCU	
Digital Acquisition	6	Default configuration, 4 High-Active Channels, 2 Low-Active Channels	MCU	
Analog Acquisition	6	Default configuration, 2 Channels with 5V voltage type, 2 Channels with 36V voltage type, 2 Channels with resistor type	MCU	
Low-Side Drive	8	8 Channels @ 250mA	MCU	
High-Side Drive	4	4 Channels @ 1A	MCU	

5V Sensor Power Supply	2	Maximum Current 100mA	MCU	
Power Positive	6			
Power Ground	7			
Signal Ground	9			

3. Mechanical Structure

3.1 Dimensional Drawing

The exterior of the controller's housing has no special treatment or coatings and is free of sharp burrs or edges.



3.2 Connectors

The connector products used in EAORA10 comply with automotive safety standards. The connector models are listed in the table below.

No.	Connector	Name	Category	Supplier	Link
1	121P	PCB Pin Header	1746979-1	TE	--
2		81P Housing	1473244-1	TE	http://www.digikey.com/products/en?keywords=1473244-1
3		40P Housing	1473252-1	TE	http://www.digikey.com/products/en?keywords=1473252-1
4		Large Terminal	964273-2	TE	http://www.digikey.com/products/en?keywords=964273-2%20
5		Small Terminal	968220-1	TE	http://www.digikey.com/products/en?keywords=968220-1
6		81P Back Cover	1473247-1	TE	http://www.digikey.com/products/en?keywords=1473247-1
7		40P Back Cover	1473255-1	TE	http://www.digikey.com/products/en?keywords=1473255-1
8		81P Clip	368382-1	TE	http://www.digikey.com/products/en?keywords=368382-1
9		40P Clip	368388-1	TE	http://www.digikey.com/products/en?keywords=368388-1
10	4-chamber waterproof connector	Board Side	2404815-1	TE	
11		Wire Side	2-2354439-1	TE	
12	4-chamber waterproof	Board Side	E3SW4A-BMR131-S00	Amphenol	

13	connector	Wire Side	E3WS4Z-WFS101-T02	Amphenol	
14	Aviation Plug	Board Side	M8-F1-S8	DAOSM	
15		Wire Side	M8-D-P8	DAOSM	
16	Antenna Interface	Water proof Antenna Interface	SMA-KKY-22.2MM	YINSAIGE	

4. Quick Start

4.1 Preparation

Before using this device, please prepare the following items:

- A stable power supply: 12V DC/10A min or 24V DC/5A min
- USB to RS-232 adapter
- A laptop

4.2 Basic Knowledge

If you are new to Linux, it might be helpful to first learn some quick tutorials on using Linux command-line tools. Here are two good tutorials: [Chinese Tutorial](#), [English Tutorial](#).

4.3 Using the Device

1. Connection

Connect the device's positive and negative terminals (BATTA as the main power supply, BATTB as the backup power supply) to the DC power source. Use the USB to RS-232 cable to connect the device's serial port 2 to the computer, and ensure the computer can properly use serial devices.

2. Configuration

Configure the serial port: baud rate 115200, 8 data bits, no parity, 1 stop bit.

On Windows, use MobaXterm or Putty; on Linux, use Minicom, etc., to open the serial port.

3. Startup

Turn on the device's KeyOn switch to power up the device. The device will first boot U-Boot, followed by the Linux system. You will see the system booting up normally in the serial terminal window. Afterward, you can log in with the default username: nvidia, and password: nvidia.

5. Hardware Description

The hardware circuitry of this computing platform is designed based on the application requirements of autonomous driving systems. The electrical parameters meet automotive-grade standards and the platform is equipped with various data transmission interfaces to meet the demands of multi-sensor fusion in autonomous driving systems. The main chip includes multiple high-performance computing units, suitable for both sequential and parallel computing characteristics of autonomous driving.

5.1 Specifications and Parameters

Item	Design Specifications
Working Voltage	DC 9~36V
Operating Memory	8GB
Storage Space	512GB SSD
Operating Temperature	-25~70°C
Operating Humidity	0~95%, no condensation
Storage Temperature	-40~85°C
Dimensions	317*180*57mm
Waterproof Rating	IP67
Cooling Method	Air Cooling

5.2 Device Ports

5.2.1 Port Distribution

The distribution of input and output ports on this computing platform is shown in the figure below.

All the views shown are front views.




Figure 1: Top View of the Controller




Figure 2: 121 Pin Connector




Figure 3: Standard Ethernet Connector




Figure 4: Camera Connector




Figure 5: Automotive Ethernet Connector



Figure 6: Antenna Connector

5.2.2 Port Definition

The functional definitions of the input and output ports on this computing platform are shown in the table below.

Signal Name	PIN	Interface Description	Remarks
E3SW Automotive Ethernet			
P1_MDI_P	E3SW-A1	Automotive Ethernet Interface 1	1000Base-T1
P1_MDI_N	E3SW-B1		
P2_MDI_P	E3SW-A2	Automotive Ethernet Interface 2	1000Base-T1
P2_MDI_N	E3SW-B2		
P3_MDI_P	E3SW-A3	Automotive Ethernet Interface 3	1000Base-T1
P3_MDI_N	E3SW-B3		
P4_MDI_P	E3SW-A4	Automotive Ethernet Interface 4	100Base-T1
P4_MDI_N	E3SW-B4		
Standard Automotive Interface			
MDI2_N	ETH-1	Standard Automotive Interface	100BASE-TX/1000BASE-T
MDI3_P	ETH-2		
MDI3_N	ETH-3		
MDI0_N	ETH-4		
MDI1_P	ETH-5		
MDI0_P	ETH-6		
MDI2_P	ETH-7		
MDI0_N	ETH-8		
Camera Interface			
Camera-1	2404815-1	GMSL/GSML2 Serial Camera Interface 1	
Camera-2	2404815-2	GMSL/GSML2 Serial Camera Interface 2	
Camera-3	2404815-3	GMSL/GSML2 Serial Camera Interface 3	
Camera-4	2404815-4	GMSL/GSML2 Serial Camera Interface 4	
Camera-5	2404815-1	GMSL/GSML2 Serial Camera Interface 5	
Camera-6	2404815-2	GMSL/GSML2 Serial Camera Interface 6	
Camera-7	2404815-3	GMSL/GSML2 Serial Camera Interface 7	
Camera-8	2404815-4	GMSL/GSML2 Serial Camera	

Signal Name	PIN	Interface Description	Remarks	
		Interface 8		
Antenna Interface				
GNSS	GNSS	GNSS Positioning Module Antenna Interface		
WIFI1	WIFI1	WIFI Module Antenna Interface 1		
WIFI2	WIFI2	WIFI Module Antenna Interface 2		
4G/5G1	4G/5G1	4G Module Antenna or 5G Module Antenna Interface 1		
5G2	5G2	5G Module Antenna Interface 2		
5G3	5G3	5G Module Antenna Interface 3		
5G4	5G4	5G Module Antenna Interface 4		
SIM Card Interface				
SIM	SIM	4G/5G SIM Card Interface		
Audio Interface				
Audio	Audio	Audio Interface		
Display Interface				
HDMI	HDMI	HDMI Display Interface		
USB Interface				
USB Host	USB	USB Interface		
Power Ground Section				
BATT	121P-1	BATTB Positive Power	BATTA is the main power supply, BATTB is the backup power supply	
	121P-3			
	121P-115			
	121P-116	BATTA Positive Power		
	121P-118			
	121P-121			
Power Ground Section				
PGND	121P-2	Power Negative Terminal		
	121P-4			
	121P-5			
	121P-114			
	121P-117			
	121P-119			
	121P-120			
Signal Ground Section				
GND	121P-36	Signal Ground Section		
	121P-45			
	121P-57			
	121P-59			

Signal Name	PIN	Interface Description	Remarks
	121P-64		
	121P-65		
	121P-82		
	121P-84		
	121P-85		
	121P-87		
	121P-93		
	121P-95		
5V Sensor Power Output Section			
5V-1	121P-83	5V-1 Sensor Power Output	Maximum current 100mA
5V-2	121P-86	5V-2 Sensor Power Output	Maximum current 100mA
Power-On Section			
KEYON39	121P-39	KEYON39	Active high, controls TC377 power-on (triggered by high level)
KEYON44	121P-44	KEYON44	Active high, controls ORIN power-on (triggered by high level)
KEYON56	121P-56	KEYON56	Active high, controls TC377 power-on (triggered by rising edge)
Analog Input Section			
AI01	121P-42	Analog Signal Input 0~5V (Voltage Type)	12-bit precision
AI02	121P-60	Analog Signal Input 0~5V (Voltage Type)	12-bit precision
AI03	121P-43	Analog Signal Input (Resistor Type)	12-bit precision
AI04	121P-24	Analog Signal Input (Resistor Type)	12-bit precision
AI13	121P-62	Analog Signal Input 0~36V (Voltage Type)	12-bit precision
AI14	121P-40	Analog Signal Input 0~36V (Voltage Type)	12-bit precision
Digital Input Section			
DI01	121P-20	Digital Signal Input 0~BATT	Active high
DI02	121P-58	Digital Signal Input 0~BATT	Active high
DI03	121P-77	Digital Signal Input 0~BATT	Active low
DI04	121P-38	Digital Signal Input 0~BATT	Active low
DI21	121P-74	Digital Signal Input 0~BATT	Active high
DI22	121P-16	Digital Signal Input 0~BATT	Active high
Output Signal Section			
HSO01	121P-88	Rated 0.5A, Maximum 1A	
HSO02	121P-89	Rated 0.5A, Maximum 1A	

Signal Name	PIN	Interface Description	Remarks
HSO03	121P-97	Rated 1A, Maximum 1.5A	
HSO04	121P-96	Rated 1A, Maximum 1.5A	
LSO01	121P-101	Rated 250mA	
LSO02	121P-94	Rated 250mA	
LSO03	121P-90	Rated 250mA	
LSO04	121P-92	Rated 250mA	
LSO05	121P-110	Rated 250mA	
LSO06	121P-103	Rated 250mA	
LSO07	121P-109	Rated 250mA	
LSO08	121P-107	Rated 250mA	

Serial Communication Interface Section

CAN_A_H	121P-27	Without 120Ω Termination Resistor	Supports CANFD and specific frame wake-up, corresponding to CANA in EcoCoder.
CAN_A_L	121P-28		
CAN_B_H	121P-9	Without 120Ω Termination Resistor	Supports CANFD and specific frame wake-up, corresponding to CANB in EcoCoder.
CAN_B_L	121P-10		
CAN_C_H	121P-31	With 120Ω Termination Resistor	Supports CANFD, corresponding to CANC in EcoCoder.
CAN_C_L	121P-32		
CAN_D_H	121P-11	With 120Ω Termination Resistor	Supports CANFD, corresponding to CAND in EcoCoder.
CAN_D_L	121P-12		
CAN_E_H	121P-29	With 120Ω Termination Resistor	Supports CANFD, corresponding to CANE in EcoCoder.
CAN_E_L	121P-30		
CAN_F_H	121P-13	With 120Ω Termination Resistor	Supports CANFD, corresponding to CANF in EcoCoder.
CAN_F_L	121P-14		
CAN_G_H	121P-18	With 120Ω Termination Resistor	Supports CANFD, corresponding to CANG in EcoCoder.
CAN_G_L	121P-17		
CAN_H_H	121P-22	With 120Ω Termination Resistor	Supports CANFD, corresponding to CANH in EcoCoder.
CAN_H_L	121P-21		
SOC_CAN0_H	121P-47	With 120Ω Termination Resistor	Supports CANFD, corresponding to CAN0 on ORIN.
SOC_CAN0_L	121P-66		
SOC_CAN1_H	121P-48	With 120Ω Termination Resistor	Supports CANFD, corresponding to CAN1 on ORIN.
SOC_CAN1_L	121P-67		
WHEELTICK_IN	121P-33	GNSS Wheel Speed and Steering Input Signals	
FWD_IN	121P-34		
CAN_SHILD-1	121P-46	CAN Shielded Cable	
CAN_SHILD-2	121P-8	CAN Shielded Cable	
RS232_1_RXD	121P-52	RS-232 Serial Port 1	ORIN ttyTHS0
RS232_1_RXD	121P-71		

Signal Name	PIN	Interface Description	Remarks
RS232_2_TXD	121P-51	RS-232 Serial Port 2	ORIN ttyTCU0 Default for Debug
RS232_2_RXD	121P-70		
Other Section			
PPS_IN	121P-23	PPS (Pulse Per Second) Synchronization Input Signal	ORIN, supports 5V-16V
PPM	121P-78		

5.3 System Main Chip

The autonomous driving processor inside the EAORA10 is the ORIN NX/NANO chip, which is designed by NVIDIA for embedded intelligent systems, including autonomous driving systems. The computational performance of the different processors is listed below:

	Jetson Orin NX Series		Jetson Orin Nano Series	
SOM	Jetson Orin NX 16GB	Jetson Orin NX 8GB	Jetson Orin Nano 8GB	Jetson Orin Nano 4GB
AI Performance	100 TOPS	70 TOPS	40 TOPS	20 TOPS
GPU	1024-core NVIDIA Ampere architecture GPU with 32 Tensor Cores		1024-core NVIDIA Ampere architecture GPU with 32 Tensor Cores	512-core NVIDIA Ampere architecture GPU with 16 Tensor Cores
Max GPU Frequency	918 MHz	765 MHz	625 MHz	
CPU	8-core Arm® Cortex®-A78AE v8.2 64-bit CPU 2MB L2 + 4MB L3	6-core Arm® Cortex® A78AE v8.2 64-bit CPU 1.5MB L2 + 4MB L3	6-core Arm® Cortex® A78AE v8.2 64-bit CPU 1.5MB L2 + 4MB L3	
Max CPU Frequency	2 GHz		1.5 GHz	

	16GB 128-bit LPDDR5 102.4GB/s	8GB 128-bit LPDDR5 102.4GB/s	8GB 128-bit LPDDR5 68 GB/s	4GB 64-bit LPDDR5 34 GB/s
Video Encoding	1x 4K60 (H.265) 3x 4K30 (H.265) 6x 1080p60 (H.265) 12x 1080p30 (H.265)			1080p30, supported by 1-2 CPU cores
Video Decoding	1x 8K30 (H.265) 2x 4K60 (H.265) 4x 4K30 (H.265) 9x 1080p60 (H.265) 18x 1080p30 (H.265)			1x 4K60 (H.265) 2x 4K30 (H.265) 5x 1080p60 (H.265) 11x 1080p30 (H.265)


The microcontroller inside the EAORA10 uses Infineon's TC377 series chip, which features a 3-core TriCore™ architecture with a working frequency of 300 MHz. It includes up to 1.1MB + 6MB of RAM with ECC (Error Correction Code) protection. The chip supports ASIL-D, the highest safety level requirement. Together with the basic chip, it enables the design of a hardware core safety architecture.

The chip resources are as follows:

Feature	Detail
Micro Control Core	32-bit Infineon TC377TP
Maximum Frequency	300MHz
Flash	6MB
SRAM	1.1MB
EEPROM	256K
Float Point Capability	Yes
SBC	TLF35584

5.4 Circuit Diagram


The internal hardware circuit structure of the EAORA10 is shown in the figure below.



5.5 Circuit Description

5.5.1 Analog Signal Input

The analog input channels have the same structure. The circuit diagram and details are shown below.




Note: 1) “--” indicates not soldered; 2) UB represents the BATT voltage; 3) AI28 collects the BATT voltage signal.

Pin #	AI	EMC Capacitor	Pull Up Resistor	Series Resistor	Divided Voltage Resistor	Filter Capacitor	Input Range		Conditions / Remarks
		(F)	to 5V (Ohm)	(Ohm)	(Ohm)	(F)	Min	Max	
42	AI01	100n	--	22k	--	1n	0V	5V	
60	AI02	100n	--	22k	--	1n	0V	5V	
43	AI03	100n	10k	22k	--	1n	--	--	Resistor Type
24	AI04	100n	10k	22k	--	1n	--	--	Resistor Type
62	AI13	100n	--	22k	3.48k	1n	0V	32V	
40	AI14	100n	--	22k	3.48k	1n	0V	32V	

5.5.2 Digital Signal Input

The digital input channels have the same structure. The circuit diagram and details are shown



below.

Note: 1) "--" indicates not soldered. 2) U_B represents the BATT voltage. 3) KEYON and DC_WAKE are only used as hardwired wake-up signals.


Pin #	DI	Pull Up Resistor	Pull Down Resistor	Operation Threshold for Input Signal		Input Range		Conditions/ Remarks
		to U_B (Ohm)	(Ohm)	V_{low}	V_{high}	Min	Max	
20	DI01	--	10k	3V	8.5V	0V	U_B	Active High
58	DI02	--	10k	3V	8.5V	0V	U_B	Active High
77	DI03	10k	--	3V	8.5V	0V	U_B	Active Low
38	DI04	10k	--	3V	8.5V	0V	U_B	Active Low
74	DI21	--	10k	3V	8.5V	0V	U_B	Active High
16	DI22	--	10k	3V	8.5V	0V	U_B	Active High

6. Basic Software

The SOC software system of this computing platform is custom-developed for autonomous driving systems. The figure below shows a typical block diagram of an autonomous driving system. The software system of this platform includes components such as RTOS and the Runtime Framework. The RTOS is the Linux operating system, and the Runtime Framework is the melodic version of ROS (Robot Operating System).

The Linux operating system bridges the gap between the underlying hardware and the user. Users can input commands through the system's user interface, and the operating system interprets the commands, drives the hardware, and fulfills the user's requests. The Linux operating system provides the following functionalities: process management, memory management, file system, networking, security mechanisms, user interface, and device drivers.

ROS offers standard operating system services such as hardware abstraction, low-level device control, common functionalities, inter-process communication, and data packet management. ROS is based on a graph architecture, allowing processes from different nodes to receive, publish, and aggregate various types of information (such as sensing, control, status, planning, etc.).




The MCU software architecture inside the ORIN computing platform is designed with reference to the AUTOSAR architecture standard, divided into the application software layer and the basic software layer. The basic software layer is further divided into the microcontroller abstraction layer, ECU

abstraction layer, service layer, and complex drivers.

The application software and basic software are integrated through EcoCoder. EcoCoder uses the s-function in Simulink to encapsulate the underlying interfaces into the Simulink block library. Application developers can use Simulink to build application-layer models and generate executable program files adapted for the TC377 with a single click in Simulink.

7. Application Scenarios


The EAORA10 is used in the field of autonomous driving, forming the hardware platform of an autonomous driving system in conjunction with sensors. The common connection methods are shown in the figure below.



8. Development Tools

The MCU software architecture inside the ORIN computing platform is designed with reference to the AUTOSAR architecture standard, divided into the application software layer and the basic software layer. The basic software layer is further divided into the microcontroller abstraction layer, ECU abstraction layer, service layer, and complex drivers.


The application software and basic software are integrated through EcoCoder. EcoCoder utilizes the s-function in Simulink to encapsulate the underlying interfaces into the Simulink block library. Application developers can use Simulink to build application-layer models and generate executable program files adapted for the TC377 with a single click in Simulink.



8.1 EcoCoder-AI

EcoCoder-AI is a powerful automatic code generation library based on Matlab/Simulink, directly linked to the target controller, enabling the import of image data and LiDAR data into the Simulink

environment. EcoCoder-AI integrates code generation, compilation, and one-click executable file generation. It allows control models built in Simulink to be directly converted into ROS-based executable programs suitable for the target controller, and then downloaded to the target controller. Additionally, it can accelerate GPU data processing. For more details, please refer to the document "*EcoCoder-AI User Manual*."




8.2 EcoCoder

EcoCoder is an application development tool for control systems that allows users to develop embedded application-layer programs more conveniently in the Simulink environment. It extends Simulink and Real-Time Workshop by providing the necessary code module resources for embedded coder generation, enabling automatic configuration and optimization of code generation. The basic software library is encapsulated as an s-function, allowing developers to use basic software interfaces and perform some basic parameter configurations in a graphical manner. It enables one-click generation of executable files and data description files, and provides an A2L address update tool.


Features:

- Users can develop embedded application-layer programs in the Simulink environment.
- Application developers can focus on control strategy development without needing to worry too much about microcontroller and hardware platform aspects, thus reducing the cost of involving low-level software and hardware engineers.

- The basic software library is encapsulated as an s-function, allowing developers to use basic software interfaces and configure parameters in a graphical way, making it easier for application developers to use low-level software.
- From the application layer model, executable files and data description files can be generated with a single click, and an A2L address update tool is provided. Automatic integration is used to automatically integrate the code generated from the application layer model with the underlying software in the background, and the makefile method is used to automatically invoke the compiler to compile and generate executable files. This eliminates the need for manual integration of application and low-level software, reducing the cost of involving software integration engineers.




Once the model simulation passes, you can generate the flashable file with a single click by using the shortcut "Ctrl+B" or by clicking the icon shown below.



Application developers can use this tool to develop applications based on the MCU inside the autonomous driving domain controller. For more details, please refer to the document "*EcoCoder User Manual*."


8.3 EcoCAL

EcoCAL is a PC-based calibration software using the CCP protocol. By loading A2L and hex files, it enables real-time observation of measured values and online calibration of calibration values. It assists control strategy developers in debugging and calibrating application software. For more details, please refer to the document "*EcoCAL User Manual*."



8.4 EcoFlash

EcoFlash is an upper computer software developed in-house, used in conjunction with BootLoader for online flashing of target program files. The CAN communication protocol uses CCP/UDS, and the supported target files for flashing include S19, mot, and hex formats.




9. Installation Guidelines

Ecotron recommends installing the ADCU (Autonomous Driving Control Unit) inside the cockpit. If the vehicle manufacturer wishes to install the ADCU in another location, the installation position should be evaluated jointly by engineers from Ecotron and the vehicle manufacturer.

The following points should be noted when installing the ADCU:


1. The ADCU and wiring harness must be securely and reliably installed, with no looseness. The ADCU should not be used to support the harness, and the layout of the ADCU wiring harness should protect all wires from damage caused by wear and overheating.
2. Installation in areas where dust can easily accumulate should be avoided, as large amounts of dust accumulation may affect the reliability of the ADCU's operation.
3. The ADCU should be installed away from locations where its casing temperature may exceed the range of -15°C to 70°C, and care should be taken to prevent heat radiation from surrounding parts from impacting the ADCU. It is recommended to install the ADCU in an area with good airflow to facilitate cooling.




4. The ADCU should be installed in areas where oil, moisture, or water splashes are unlikely to reach.
5. The installation location and method of securing the ADCU should prevent it from being subjected to additional mechanical vibration and external impact. Avoid installing the ADCU at

resonance points of the vehicle body.

6. The ADCU should not be installed in areas where it may come into contact with the battery or where acidic or alkaline solutions might leak, as well as in areas prone to corrosion.
7. The ADCU should be installed away from places where it might come into contact with the positive battery terminal or ignition power terminal.
8. When installing the ADCU, the connectors should be oriented at a downward angle both horizontally and vertically to prevent water from entering the connectors. The recommended horizontal installation angle is between -170° and -10°, and the recommended vertical installation angle is between -170° and -10°, as shown in the figure.





Ecotron recommends using the four mounting points on the ADCU itself for installation and securing. It is recommended to use metal materials, such as aluminum alloy, for the mounting bracket, and the casing should be reliably electrically connected to the vehicle body through the bracket. If other materials are used, the customer must ensure that the ADCU's requirements for vibration, heat dissipation, temperature, and EMC (Electromagnetic Compatibility) are met. If there are any deviations, they must be confirmed with Ecotron.

9. During the installation of the wiring harness, ensure that high-speed signal cables, such as Ethernet cables and video cables, are kept as far away as possible from high-voltage and radiated interference areas like motors, battery packs, and DC-DC converters.